

Monkey



HONDA
One HEART.

KNOWS HOW TO
HAVE FUN

THE TIMELESS JOY



CUTE OUTSIDE
BEAST INSIDE



ALL LED LIGHTING SYSTEM



ABS WITH INERTIAL MEASUREMENT UNIT

NEW FRAME COLOR

NEW SEAT PATTERN

NEW COLOR STRIPE

INVERTED FRONT SUSPENSION



DIGITAL PANELMETER



ANTI THEFT ALARM & ANSWER BACK SYSTEM

IT'S MONKEY FICATION.

Dimension	
Length x Width x Height	: 1.710 x 755 x 1.030 mm
Wheelbase	: 1.145 mm
Ground Clearance	: 175 mm
Seat Height	: 775 mm
Curb Weight	: 104 kg
Fuel Tank Capacity	: 5,0 liter
Engine	
Engine Type	: 4-stroke SOHC 2-Valve
Cooling System	: Air-cooled
Fuel Supply System	: PGM-FI
Displacement	: 124 cc
Bore x Stroke	: 50 x 63,1 mm
Compression Ratio	: 10 : 1
Maximum Power	: 6,9 kW / 6.750 rpm
Maximum Torque	: 11 Nm / 5.500 rpm
Transmission	: Manual, 5-Speed
Starting System	: Electric
Clutch System	: Wet, Multiple Clutch
Oil Capacity	: 0,9 liter (Periodic Exchange)
Frame	
Frame Type	: Backbone, Steel
Front Tire Size	: 120/80-12 65J
Rear Tire Size	: 130/80-12 60J
Front Brake	: Hydraulic, Single 220 mm disc with ABS
Rear Brake	: Hydraulic, Single 190 mm disc
Brake System	: ABS Single Channel
Front Suspension Type	: Showa, 31 mm Inverted Telescopic Fork
Rear Suspension Type	: Showa, Twin Shock
Electrical	
Ignition Type	: Full Transistorized
Battery	: 12V-3Ah
Spark Plug Type	: NGK CPR7EA-9S
Headlight	: LED

PICK YOUR COLOR PICK YOUR **FUN**



PEARL NEBULA RED



BANANA YELLOW



PEARL SHINING BLACK




HONDA
One HEART.

#CARIAMAN
sangat naik motor

Gunakan setelan helm, passing tali pengikat dan kacamata secara benar.
Gunakan jaket lengan panjang dan sarung tangan yang dirancang untuk kenyamanan dan keamanan berkendara.
Pakai helm yang panjangnya pas dan nyaman serta gunakan sepatu untuk stabilitas saat kaki berpijak.



Honda Customer Care
1-500-989
0811-9-500-989
customer.care@astra.honda.com

welovehonda Indonesia
welovehonda
welovehonda_id
welovehonda Indonesia
welovehonda

www.astra-honda.com

Dan Perawatan yang benar:
• Periksa tingkat permukaan oli dan gantilah sesuai AMM Oil.
• Periksa rem dan tekanan udara ban.
• Gantikan Honda Genuine Parts, suku cadang asli sepeda motor Honda yang didistribusikan oleh PT Astra Honda Motor.
• Lakukan perawatan rutin di bengkel bergelung resmi Honda (ARSS).

Distribusikan oleh:
AHM
PT Astra Honda Motor

